

## Mounting Adjustments

The Birnabag becomes an integrated part of any child carrier and it grows with the child.

Attach the Birnabag to the outside of the child carrier with 4 straps:



1. Fasten the straps by the zipper to the upper-back part of the carrier in line with the neck of the child. The mode of attachment varies according to the carrier type:  
Use the top of the carrier, the handle, strings on the sides or on the back of the carrier.
2. Fasten the straps in the front to the upper part of the carrier between the carrying-straps on the child-carrier and the back of the carrier.
3. Fasten the straps in the middle around the carrier.
4. Fasten the straps on the lower part to the carrier hoops on each side.

Adjustments:

5. Close the bag with buttons.
6. Adjust for better fit and the size of the hood.
7. Adjust for better fit underneath and for better fit around the carrier.
8. Adjust for better fit on both sides

Pockets (orange) with logo on are ment for leftover straps after adjustments.

9. A Zipper on the back of the bag makes for easy access to the pockets on the child carrier. It can be opened from top and bottom to fasten the child to the pram, bike-trailer or pulk.

10. Close the bag with buttons in front when used seperately.

11. The packbag is a backpack. Use it an extra pocket by fasten it inside the birnabag, or use it as a backpack.

